



Schemat ideowy odbiornika ARZ-51: V₁ — 6A10, V₂ — 6B8, V₃ — 6P6, V₄ — 6C5