



ECH21



6F31
(6BA6)



Pozycja przełącznika	Kontakty przełącznika P 3	
1	1'-3'	-
2	1'-3'	7-12
3	1'-3'	8-12
4	3'-6'	-
5	3'-6'	10-12
6	3'-6'	11-12



Schemat ideowy odbior



Zakresy falowe	Kontakty przełącznika P ₂	Kontakty przełącznika P ₁
13,5 - 51,5 m	1'-2', 7'-8	9-10, 1'-2', 6'-7'-8
185 - 572 m	6-12 1'-3'	9-10, 1'-3', 7'-8'
1000 - 2000 m	1'-4'	9-10, 1'-4'
Adapter	1'-5'	10-11, 1'-5'

owy odbiornika Tesla 621A „Opera“